

Ademco 4120 EC / First Alert 200 C

Zones - 8 Hardwired

Wireless - No

Batteries - Standard 12 volt rechargeable inside main panel
AC Transformer is 16.5 volts screwed into outlet somewhere in house

Downloadable - Yes

Panic Buttons - Police Panic - * and # (some systems may have different arrangement)

Fire Panic - 1 and *

Medical Panic - 3 and #

Status - Press * if keypad shows NOT READY to view open zones

Arm Away - 4-digit code + 2 (AWAY)

Arm Stay - 4 digit code + 3 (STAY), arms all but motions

Instant Arm - 4 digit code + 7 (INSTANT), also bypasses motions

Max Arming - 4-digit code + 4 (MAX), arms everything including motions instant

Quick-Arm Press # + 2 for AWAY, # + 3 for STAY

Disarm - 4 digit code + 1 (OFF)

Silence Alarm - 4 digit code + 1 (OFF) twice to turn off siren and reset display

Bypass - 4-digit code + 6 (BYPASS) + zone (01 to 08)
(Keypad will beep, BYPASS and Zone should Flash. now Arm system)

Alarm Memory - There is no alarm memory or event buffer

Reset Smoke - 4-digit code + 1 (OFF) twice to turn off siren and reset smoke (If this does NOT reset smoke detector set for service, smoke is bad)

Door Chimes - 4-digit code + 9 (CHIME)

Test Sensors 4-Digit Code + 5 (TEST)

Keypad will beep every 3 minutes

Open sensors and keypad will sound

End test with 4-digit Code + 1 (OFF) key